


# KENT VARIATIONS

Select your style choices for Cover (A) - Arm (B) - Seat (C) - Back (D) - Base (E)


## ARMS B15, B19 & B21

Choose these codes to create your arm style with t-cushions

### Step 1: Choose your arm (B)




### Step 2: Choose your seat (C) T-Cushion Options Only




## ARMS B14, B16, B17, B18, B20, B22 & B23

Choose these codes to create your style with straight cushions


### Step 1: Choose your arm (B)





### Step 2: Choose your seat (C) Straight Cushion Options Only




### Step 3: Choose your back (D)



D71 & D72 are only available on club chair & club swivel




### Step 4: Choose your base (E)



#### Notes:

- 4395L standard leg on 123499 (no options)
- E24 is not available with arm B21

### Optional leg choices for Bases E21 & E22 (front only)



\*\* to choose cup caster color on the 4218L, order these specific leg numbers:

- 4218LA - Antique Brass
- 4218LP - Pewter
- 4218LS - Silver